




No.	Product Model#	Part Number	Description	Qty
1	FX1331-Z	3133417001	Decorative Cover	1
2	FX1331-Z	2829184001	Gear Case Assembly	1
3	FX1331-Z	2751493001	Rotor Set	1
4	FX1331-Z	2831301001	Electric Assembly	1
5	FX1331-Z	2829997001	L R Housing Set	1
6	FX1331-Z	3707622001	Buckle	1
7	FX1331-Z	5620039010	Screw	2
8	FX1331-Z	3127743001	Bit Holder	1
9	FX1331-Z	5610241002	Screw	9
10	FX1331-Z	4870911001	Switch Assembly	1
11	FX1331-Z	3133188001	F/R Button	1

Repairable or not	Standard repair time (min)
Yes	1
Yes	3
Yes	4
Yes	6
Yes	6
Yes	1
Yes	1
Yes	1
Yes	1
Yes	6
Yes	3