




No.	Product Model#	Part Number	Description	Qty
1	FX1472-Z	2850420001	Output Shaft Assembly	1
2	FX1472-Z	5620704003	Screw and Washer	4
3	FX1472-Z	2851147001	Front Gear Housing Assembly	1
4	FX1472-Z	5651073001	Plain Washer	1
5	FX1472-Z	2851148001	Impact Block Assembly	1
6	FX1472-Z	3709587001	Gasket	4
7	FX1472-Z	2851180001	Planet Gear Assembly	1
8	FX1472-Z	2851156001	Gear Case Assembly	1
9	FX1472-Z	5690423001	O Ring	1
10	FX1472-Z	2751595001	Rotor Assembly	1
11	FX1472-Z	2851187001	L R Decorative Frame Set	1
12	FX1472-Z	3323583001	Rear Cover	1
13	FX1472-Z	5611177001	Screw and Washer Assembly	4
14	FX1472-Z	3132976001	Vibration Attenuation Pad	4
15	FX1472-Z	5610225002	Hexagon Lobuar Screw	2
16	FX1472-Z	5610876001	Hexalobular Socket Tapping Screw	5
17	FX1472-Z	2850424001	L R Housing Set	1
18	FX1472-Z	3133334001	F/R Button	1
19	FX1472-Z	4870912001	Switch Assembly	1
20	FX1472-Z	3650343001	Lantern Ring	1
21	FX1472-Z	3127733001	LED Cover	1
22	FX1472-Z	2851149001	Button Assembly	1
23	FX1472-Z	3123928002	Rubber Pole	2

