



Service Part List_FX1451-Z_Version A

No.	Product Model#	Part Number	Description	Qty
1	FX1451-Z	2828953001	Front Gear Housing Assembly	1
2	FX1451-Z	3132976001	Vibration Attenuation Pad	4
3	FX1451-Z	5650897001	Plain Washer	1
4	FX1451-Z	2829040001	Output Shaft Assembly	1
5	FX1451-Z	2825458001	Impact Block Assembly	1
6	FX1451-Z	5690324001	O Ring	1
7	FX1451-Z	2829058001	Rear Gear Case Assembly	1
8	FX1451-Z	5610875001	Screw and Washer Assembly	4
9	FX1451-Z	2831302001	Electric Assembly	1
10	FX1451-Z	5690531001	Rubber Ring	1
11	FX1451-Z	3133254001	Pressure Plate	1
12	FX1451-Z	2824833001	Rotor Set	1
13	FX1451-Z	3323185002	Rear Cover	1
14	FX1451-Z	5610895001	Screw and Washer Assembly	4
15	FX1451-Z	5610225002	Hexagon Lobuar Screw	2
16	FX1451-Z	4870911001	Switch Assembly	1
17	FX1451-Z	3133188001	F/R Button	1
18	FX1451-Z	2829043001	L R Handle Set	1
19	FX1451-Z	5610876001	Socket Tapping Screw	5
20	FX1451-Z	5620039012	Screw	1
21	FX1451-Z	3707622001	Buckle	1